## www.EntraPASS.com

## **RS-485 Protocol Converters**

**USB-485** 

- Converts USB to RS-485
- Extends communication up to 4,000 ft. (1,200 m)
- Uses unshielded, twisted communication cable
- Supports up to 32 EntraPASS controllers
- Powered by USB port
  Supports Windows 98, NT, Me, 2000, XP

VC-485

- Converts RS-232 to RS-485
- Extends communication up to 4,000 ft. (1,200 m)
- Uses unshielded, twisted communication cable
- Supports up to 32 EntraPASS controllers
- Requires 5VDC or 12VDC power

**Ordering Information** 

USB to RS-485 communication interface

VC-485 RS-232 to RS-485 multi-function communication interface



USB-485



VC-485