



Firmware installation instructions for the TURNSTILES KT300 v01.xx

After the download, extract the contents of the zip file (.bin and .txt file) to the FIRMWARE folder of your system installation.

To install the firmware with EntraPass Corporate or Special Edition:

1. Specify the firmware's directory from the Options\Firmware tab
2. Reload it from the Operation\Controller\Reload Firmware. If you have any questions before reloading controller firmware please contact TURNSTILES Technical Support.



8641 S. Warhawk Rd. Conifer, CO 80433
(303) 670-1099 x11 (303) 679-8949 fax
Patrick.McAllister@TURNSTILES.us